

Revolution AIRBRUSH SERIES

HP-TR1 | HP-TR2
Operating Instruction Manual

R500-IM-OJZ

EFFORTLESS COVERAGE[™] 手頃で手軽

Iwata Revolution Series and NEO For Iwata Series airbrushes deliver soft, effortless coverage at low air pressures. Fine atomization is achieved with the smallest of air compressors, making these airbrushes a simple choice for medium spray applications and for anyone wanting to start airbrushing for the first time.

NEED ASSISTANCE ?

If you have any issues or warranty service questions, contact your local ANEST IWATA affiliate <u>before</u> returning to your place of purchase.

ANEST IWATA-MEDEA, INC.

Portland, Oregon U.S.A. +1-503-253-7308 (M-F) info@iwata-medea.com www.iwata-airbrush.com

ANEST IWATA SOUTH-EAST ASIA CO., LTD.

Bangkok, Thailand +66-(0)-2643-2870 www.anest-iwatasoutheastasia.com

ANEST IWATA SOUTH AFRICA (PTY) LTD.

Johannesburg, Republic of South Africa +27-11-463-2169/2265/2223 www.anest-iwata.co.za

ANEST IWATA CORPORATION

Yokohama, Japan +81-(0)45-591-1111 www.anest-iwata.co.jp

ANEST IWATA STRATEGIC CENTER

Cardano al Campo, Italy +39-0331-733120 www.anest-iwataeu.com

ANEST IWATA SHANGHAI

Shanghai, China +86-(0)21-6407-9713 / 15 / 16 www.anest-iwata-sh.com

ANEST IWATA RUS LLC

Moscow, Russia +7-495-938-77-28 www.anestiwata.ru

ANEST IWATA AUSTRALIA PTY LTD.

Mt. Druitt, NSW +61-(02)-9853-2000 www.anest-iwata.com.au

ANEST IWATA (U.K.) LTD.

Neots Cambs, England +44-(0)1480-405419 www.anest-iwata.co.uk

ANEST IWATA MOTHERSON LTD.

Uttar Pradesh, India +91-(0)120-4600500 / 14 / 17 www.anest-iwata.co.jp

CENTURY TRADING CO., LTD.

Seoul, Korea 82-2-2163-0300 www.centrading.co.kr



Iwata Revolution TRI

- Pistol trigger design allows fixed, dual action operation.
- Internal mix airbrush.
- Ergonomic, balanced handle for easy, level spraying.
- Spray pattern .75" down to hairlines.
- Replaceable, internal PTFE needle packing for use with solvent-based paints.
- R3 head system
- FA450 Iwata Pistol Grip Filter defends against moisture.
- Side-feed airbrush design allows the use of side-feed bottles and cups.
- .25 oz side-mounted color cup.



Iwata Revolution TR2

- Pistol trigger design allows fixed, dual-action operation.
- · Internal mix airbrush.
- Ergonomic, balanced handle for easy, level spraying.
- Spray pattern 1.5" down to fine lines.
- Replaceable, internal PTFE needle packing for use with solvent-based paints.
- R5 head system
- FA 450 Iwata Pistol Grip Filter defends against moisture.
- Side-feed airbrush design allows the use of side-feed bottles and cups.
- .5 oz side-mounted color cup.

GETTING STARTED REVOLUTION TRI, TR2

Compressor

Choose an appropriate compressor for your Revolution airbrush. The lwata Sprint Jet and Smart Jet compressors are good beginner's choices and will provide approximately 30 psi of air pressure to the Revolution. 30 psi provides a finely atomized background spray in addition to controllable fine detail performance.

Assembly

- 1. Screw the airhose onto the compressor.
- 2. Screw the airhose onto the airbrush.

- If using a Power Jet, Power Jet Lite, or Power Jet Pro compressor, adjust the pressure to between 30 and 45 psi.
- 4. Check for any air leaks in the compressor or airhoses
- 5. Place a few drops of cleaner into the bowl.
- 6. Point the airbrush away from you.
- 7. Pull back on the trigger (#9) a little to start the flow of air through the airbrush.
- Pull back on the trigger all the way to fully open the nozzle of the airbrush.
- Spray cleaning solution through the airbrush to rinse out any residual pre-testing pigment.

GENERAL OPERATION REVOLUTION TRI, TR2

Spraying

- Pull the trigger (#9) back slightly and only the air will come out.
- Pull the trigger back more until paint starts to spray in small amounts.
- Pulling the trigger back further releases even more paint until the trigger is pulled as far as it can go.

Fine-Line Spray

- 1. Pull the trigger (#9) slightly back to start airflow.
- 2. Position the airbrush close to the surface, between 1/16 and 1/2 inch is common.

3. Pull the trigger back more to start the flow of paint.

Stippling

Iwata air brushes are designed to produce a wide range of stippling

- 1. Unscrew the needle cap (#1)
- 2. Unscrew the nozzle cap (#2)
- **3.** Adjust the air pressure between 5 and 50 psi. Lower air pressure will give you coarse stipple whereas higher pressure will provide a fine stipple effect. Paint viscosity will also effect the stippling texture.

Line thickness can be controlled by adjusting the distance between the airbrush and the surface and also by varying the paint flow by manipulating the trigger's position.

An extremely narrow line can be obtained by carefully removing the needle cap (#1) and positioning the airbrush closer to the surface.

CAUTION: The needle and nozzle are very delicate. Even a slight bend on the tip of the needle can adversely effect the spray pattern.

Wide-Line and Background Spraying

- 1. Pull the trigger (#9) slightly back to start airflow.
- Position the airbrush further away from the surface, from ½ to 6 inches is common.
- Pull the trigger back much further releasing more paint to cover the bigger area.

Increase the distance between the airbrush and painted surface to control the line's width. Increasing the air pressure will also effect the spray width. The Revolution's maximum usable line width is approximately $2\frac{1}{2}$ inches.

Air Pressure

For the Revolution, working pressures generally vary between 20 and 60 psi, depending on what type of work is being

done and what textures are desired. A good working pressure may average around 25 psi. The viscosity of the paint and your desired spray characteristics will also effect your ideal pressure. As a general rule, larger amounts of paint, or thicker paints, will be sprayed with higher pressures. WARNING: Do not exceed 100psi

Paint Preparation

For non-specific airbrush paints proper preparation, including filtering the paint through a nylon mesh, is recommended for best performance. Paint should be thinned with its proper solvent. It is best to prepare paint relatively thin and make repeated passes across the work to achieve the desired shade. This will also improve the quality of your work and decrease the cleaning time of your airbrush.

Safety Tips

- · Always spray in a well ventilated area.
- Do not spray solvent-based (flammable) paints around open flames.
- Use the appropriate respirator to safely filter out the paint vapors particular to the kind of paint you are using.
- · Wear eye protection to prevent paint contact with eyes.
- Never use air pressure that exceeds the airbrush's limit. (100 psi)

MAINTENANCE

Choose an Cleaning the Airbrush Between Colors

- 1. Dump out the color cup's excess paint.
- 2. Rinse the cup with the appropriate cleaning solution.
- 3. Use a paper towel to wipe out any left-over paint.
- 4. Fill the bottom of the cup with cleaner.
- 5. Spray cleaner until the spray is clear.
- 6. Add the next color to the color cup.
- 7. Repeat cleaning procedure when finished.

Cleaning the Needle

- 1. Unscrew the handle (#16) from the airbrush body.
- 2. Loosen the needle chucking nut (#14).
- 3. Gently pull the needle (#13) straight out.
- 4. Fold a soft cloth damp with cleaner over the needle.
- 5. Rotate the needle to gently wipe the residual paint off.
- **6.** Carefully insert the needle into the airbrush until it seats fully against the nozzle (#3).
- 7. Tighten the needle chucking nut finger tight.
 - Pull the trigger back and forth to visually confirm the needle's ability to move.
- 8. Screw the handle back onto the airbrush body.

Before Each Session

Spray water, or the appropriate paint solvent, through the airbrush to make sure the airbrush is working properly.

After Each Session

Or any time the airbrush becomes clogged.

- 1. Increase the air pressure.
- 2. Spray cleaning solution for a short time.
- 3. Clean the needle if necessary

Cleaning the airbrush this way helps clean the paint passage, the nozzle, and the needle thoroughly.

Periodically

To ensure smooth main lever action lubricate the needle (#17) and the main lever mechanism (#10 or #11) regularly.

- I. Unscrew the handle (#17 or #18).
- 2. Loosen the needle chucking nut (#16).
- 3. Remove the needle.
- Coat the needle lightly with a high-quality lubricant, like Medea Super Lube.
- **5.** Wipe the needle with a soft, clean cloth, leaving a light coat of lube behind.
- 6. Re-insert the needle gently into the airbrush.
- 7. Tighten the needle chucking nut.
- 8. Screw the handle onto the airbrush body.
- **9.** Drip I drop of lube into the slot directly behind the main lever and as close to the main lever as possible.

DO NOT over-lube the needle or the main lever mechanism, since it is possible to transfer excess lube into the nozzle causing severe paint flow problems.

DO NOT use light machine oil or WD-40 for lubrication. These will cause the needle to stick as it moves through the needle packing o-ring.

CAUTION:If it becomes absolutely necessary to dismantle the airbrush remember that in most situations tools are not needed. DO NOT use pliers. If needed use the provided wrench to unscrew the head cap (#3).



NEVER soak your entire airbrush in any liquid. NEVER store your airbrush with spray medium or cleaning agents in the fluid cup.

	TROUBLESHOOTING PROCEDU	RES		
Symptom	Problem	Solution		
•Bubbles in color cup or bottle	 Loose nozzle cap 	•Tighten (#2) finger tight		
	 Improper nozzle to body connection Cracked or damaged nozzle 	 See nozzle (#3) to reseat the nozzle See nozzle (#3) to replace the nozzle 		
•Double line	 Dried paint on needle tip (Tip-Dry) 	•See cleaning the needle		
	•Dirty airbrush	 See cleaning the airbrush between colors See cleaning the needle 		
	•Debris on nozzle tip	 See nozzle (#3) and clean nozzle with toothpick 		
	 Bent needle 	See needle (#15) to replace needle		
	 Cracked or damaged nozzle 	 See nozzle (#3) to replace the nozzle 		
•Not spraying	 Loose needle chucking nut 	•Finger tighten (#16)		
	 Needle stuck 	Pull/break-free needle (#15)		
	•Improper air pressure	 See specific compressor instructions to raise or lower the air pressure 		
	 Paint too thick 	•See paint preparation		
	 Cup vent hole is plugged 	 Use pushpin to unclog vent hole 		
	•Clogged nozzle	 See nozzle (#3) and clean nozzle with toothpick 		
	 Cracked or damaged nozzle 	•See nozzle (#3) to replace the nozzle		

⚠ Nozzle contains Nickel.

	TROUBLESHOOTING PROCEDU	RES
Symptom	Problem	Solution
•Skipping	 Dried paint on needle tip (Tip-Dry) 	•Clean with cotton swab dipped in cleaner
	Pigment too thick	 See paint preparation
	•Air pressure too high	 See specific compressor instructions to lower the air pressure
	 Improper nozzle to body connection 	•See nozzle (#3) to reseat the nozzle
	•Dirty airbrush	 See cleaning the airbrush between colors See cleaning the needle
	 Cracked or damaged nozzle 	•See nozzle (#3) to replace the nozzle
•Spattering	 Dried paint on needle tip (Tip-Dry) 	 Clean with cotton swab dipped in cleaner
	 Pigment build-up in needle cap 	 Unscrew #1 and clean with cotton swab
	•Air pressure too low	 See specific compressor instructions to raise the air pressure
	Pigment too thick	 See paint preparation
	•Dirty airbrush	 See cleaning the airbrush between colors See cleaning the needle
•Trigger sticks (back and forth)	Dirty airbrush	•See cleaning the airbrush between colors
		•See cleaning the needle
•Trigger sticks (up and down)	 Dried out air valve packing o-ring 	•Lube trigger shaft

riangle Nozzle contains Nickel.

REPLACEMENT PARTS AND ACCESSORIES

Nozzle (#3)

In time, the nozzle may wear or be damaged and may need to be replaced.

- I. Unscrew the handle (#16).
- 2. Loosen the needle chucking nut (#14).
- Gently pull the needle (#13) part way back. It doesn't need to be fully pulled out.
- 4. Unscrew the nozzle cap (#2)
- 5. Unscrew nozzle counter-clockwise with provided wrench.
- 6. Screw new nozzle into the airbrush body with your fingers.
- 7. Slightly tighten the nozzle with the provided wrench.

DO NOT OVER TIGHTEN!

- 8. Screw the nozzle cap onto the airbrush body.
- 9. Push needle all the way forward until it seats with new nozzle.
- 10. Tighten the needle chucking nut.
- 11. Screw the handle onto the airbrush body.
- TIP: Keep a spare nozzle on hand for unforeseen accidents.



Needle (#13)

Iwata needles are made of precision ground and hardened stainless steel that will withstand prolonged usage. They are, however, subject to easy physical damage because of the long tapered, extremely fine tip. If the needle point becomes severely bent, it must be straightened before pulling it back through the nozzle. If not, the bent needle might damage the nozzle as it's pulled through. TIP: Keep a spare needle on hand for unforeseen accidents.

Quick Disconnect (Optional Accessory)

A quick disconnect joint is screwed onto the airhose and a quick disconnect adapter is screwed onto each airbrush. When using multiple airbrushes the quick disconnect joint facilitates changing airbrushes on the same airhose quickly.

Side-Feed Color Bottles and Cups (Optional Accessory)

Several bottle sets and styles are available. From Crystal Clear bottles for water-based paints to the solvent-impervious High Strength translucent bottles, Iwata offers a wide assortment of bottles for every application. Chrome-plated side mounted cups are also available in 1/8 and 1/4 oz sizes.


Color Bottles (Optional Accessory for BCR and SAR)

Several bottle sets and styles are available. From Crystal Clear bottles for water based paints to the solvent impervious High Strength translucent bottles, Iwata offers a wide assortment of bottles for every application.

Pistol-Grip Moisture Filter

The Iwata Pistol-Grip Moisture Filter delivers clean, dry air to your airbrush. Miniature in size, the super-fine, 5-micron filter element performs like a full-size filter separator.

The clear filter bowl allows visual inspection of built up moisture. Release the water by pulling the spring-loaded release valve.



— IWATA REVOLUTION HP-TR1 | HP-TR2 —

ø	ITEM DESCRIPTION		PRICE CODE	ITEM #	HP-TR1	HP-TR2	ALSO FITS
1	Needle Cap		А	17011	•	•	BCR, CR, SAR
2	Nozzle Cap	R3	C	17022		х	AR, BR
		R5	C	17021	х		BCR, CR, SAR
3	Nozzle	R3	(17042		х	AR, BR
		R5	C	17041	x		BCR, CR, SAR
4	Body*		-	-		х	
			-	-	x		
7	Needle Packing Screw		C	17252			
7a	Needle Packing (PTFE)		A	I 1502			
9	Trigger		- 1	17141			
10	Needle Chucking Guide		F	17152			
11	Needle Spring		A	17703			
12	Spring Guide		Н	17702			
13	Needle	R3	C	17174		х	
		R5	C	17175	х		
14	Needle Chucking Nut		А	I 120 2			All
16	Handle		D	17192			SAR

#	ITEM DESCRIPTION		PRICE CODE	ITEM #	HP-TR1	HP-TR2	ALSO FITS
18a	Cup Lid		C	16181	•	opt	CR, CS, C, C+, CH, CM-C
18b	Cup Lid		F	1718 2	opt		TH
19	Air Valve O-ring		А	I 145 1	•	HI-LINE	HP, HP+,
24	Trigger Screw		(17142			
25	Pistol-Grip Filter		F	F A450			All
26	Blanking Cover		A	1045 2	•	•	SBS, SB, SB+, CM-SB
27	Valve Piston		(1713 1			
28	Main Body Ring Scre	w	A	1731 2			
29	Slide Cam		- 1	1730 1			
30	Slide Cam Spring		В	1730 2			
31	Main Body Ring		D	1731 1			
32a	Gravity Side Cup	1/3 oz	G	1720 1	•	opt	SBS, SB, SB+ CM-SB
32b	Gravity Side Cup	1/2 oz	G	1070 6	opt	•	SBS, SB, SB+ CM-SB
33	Air Valve Set		G	17121			
34	Spanner		А	I 165 1	•	•	

= yes X = no 0PT = optional "Replacement parts not available.



All Iwata airbrushes are warranted against all manufacturing defects of material and manufacture or workmanship for a period of FIVE years from date of purchase. This warranty does not cover needles, nozzles, o-rings and internal packings since these parts need to be replaced occasionally due to normal wear. Any other parts or materials that are or become defective so as not to be usable within this period will be repaired or replaced. This warranty does not cover damage caused by negligence or airbrushes which have been altered or abused in any way.



www.iwata-airbrush.com